













HD WI-FI CAMERA
BC7PW



: Start up	: Configuring
: Pairing mode	: OK

- 2.4Ghz IEEE802.11 b/g/n ->150Mbps
- 64/128-bit WEP, WPA/WPA2, WPA-PSK/WPA2-PSK
- f=2.5mm, F=2.0 1/8" CMOS sensor, angle: 120°
- 1280x720 / 640x480

- Firmware upgrade
- Input : ~ 100-240V, 50/60Hz 0,2A
Output : 5V 0.8 A
- 99 x 60 x 60mm / 3,90 x 2.36 x 2.36"
- 272 g / 9.6 oz



CamPad Application



- Download and install the BeeWi CamPad app.
- Télécharger et installer l'application BeeWi CamPad.
- Laden Sie die BeeWi SmartPad-App herunter und installieren Sie sie.
- Scaricare e installare l'applicazione BeeWi CamPad.
- Descargar e instalar la aplicación BeeWi CamPad.
- Carregar e instalar a aplicação BeeWi CamPad.
- Download en installeer de applicatie BeeWi CamPad.
- Загрузить и установить приложение BeeWi CamPad.
- Pobierz i zainstaluj aplikację BeeWi CamPad.

Full user guide / Guide complet d'utilisation / Vollständige Bedienungsanleitung / Guida utente completa / Guía de usuario completa / Guia completo do usuário / Volledige gebruikershandleiding / Полное руководство пользователя / Pełny podręcznik użytkownika



Other BeeWi Smart Home devices :

